

FAUCET ADAPTER

Instructions For Use

The Faucet Adapter allows you to attach a garden hose to your indoor faucet. In addition to filling your spa with water, the Faucet Adapter can be used to drain water from the spa.

To use the Faucet Adapter, remove the fittings from your current faucet. Thread the unit onto the faucet (there are several adapters included to fit most faucets) and attach a garden hose to the middle outlet.

To fill, raise and twist the bottom adjustment clockwise until closed. Turn on water. To drain, twist the bottom fill/drain adjustment counter-clockwise and down until it is fully open. Turn on the faucet. The tap water will exit the bottom of Faucet Adapter and create a siphon action to draw water from the spa and through the Faucet Adapter.

© Essentials 2006 • Cumming, GA 30041

